

AGES 5 & UP

MULTI-LINK 800

HOW TO OPERATE YOUR TRANSCIVER



1. Remove pull tag and turn the "ON-OFF" switch to the "ON" position. Your transceiver is now ready to operate.
2. To transmit, speak into microphone, then stop speaking to receive transmission back.
3. When transmitting, speak in a clear voice with the microphone about three inches (7.5cm) from your mouth. Best transmission and reception are achieved when the antenna is held in a vertical position.

HOW TO ATTACH THE WALKIE TALKIES ON YOUR EAR

1. Press the "EARPIECE RELEASE LEVER" to expand "EARPIECE" out.
2. Place EARPIECE on your ear carefully, with "EARPIECE" behind ear and "SPEAKER" resting in front of ear.
3. Release "EARPIECE RELEASE LEVER" and adjust unit on ear accordingly.

CAUTION:

1. You transceiver set has been fully adjusted prior to shipment from the factory.
2. Be sure not to touch the internal components other than to replace batteries.
3. When the sound becomes weak, it is time to change the battery.
4. After use, always turn the "ON-OFF" switch to the "OFF" position.
5. Keep your set in a clean, dry place.
6. Modifications not authorized by the manufacturer may void user authority to operate this device.



BATTERY REPLACEMENT

REMOVE SCREW TO OPEN BATTERY COMPARTMENT COVER. THIS UNIT REQUIRES 4 "AG13" BATTERIES (NOT INCLUDED). ALWAYS REPLACE ALL FOUR BATTERIES AT THE SAME TIME. REPLACE BATTERY COMPARTMENT COVER AND SCREW. ALKALINE BATTERIES ARE RECOMMENDED FOR BEST PERFORMANCE.

DO NOT MIX OLD AND NEW BATTERIES.
DO NOT MIX ALKALINE, STANDARD (CARBON-ZINC), OR RECHARGEABLE (NICKEL-CADMIUM) BATTERIES.

NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY. EXHAUSTED BATTERIES ARE TO BE REMOVED FROM THE TOY. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED.

RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION.

ONLY BATTERIES OF THE SAME OR EQUIVALENT TYPE AS RECOMMENDED ARE TO BE USED.

DO NOT DISPOSE OF BATTERIES IN FIRE, BATTERIES MAY EXPLODE OR LEAK.



because kidz like toyz **KIDZ TOYZ, INC. MT. KISCO, N.Y. 10549**

For Product Questions,
Call 1-877-KIDZTOY (877-543-9869)
Ask for **CUSTOMER SERVICE.**
Only in the U.S. and CANADA

Please visit us on the web at
www.kidztoyz.com



87-11504-45628

KAWASAKI® IS A TRADEMARK LICENSED BY
KAWASAKI MOTORS CORP., U.S.A.,
WHICH DOES NOT MANUFACTURE OR DISTRIBUTE THIS PRODUCT.
CONSUMER INQUIRIES SHOULD BE DIRECTED TO
KIDZ TOYZ, INC., 280 NORTH BEDFORD ROAD,
SUITE 203, MT. KISCO, NEW YORK 10549 USA

MADE IN CHINA ITEM NO. 22232