

AGES 5 & UP

MUSIC CENTER KEYBOARD™

SPEAKER



BATTERY COMPARTMENT

KEYBOARD

To Operate

1. Press any of the black or white keys. Sounds will be heard through the speaker on the left hand side of the keyboard.
2. Sounds will automatically stop when no keys are being pressed.




because kidz like toyz

KIDZ TOYZ, INC. MT. KISCO, N.Y. 10549

For Product Questions,
Call 1-877-KIDZTOY (877-543-9869)
Ask for CUSTOMER SERVICE.
Only in the U.S. and CANADA

Please visit us on the web at www.kidztoyz.com



BATTERY REPLACEMENT

REMOVE SCREW TO OPEN BATTERY COMPARTMENT COVER. THIS UNIT REQUIRES 2 "AA" BATTERIES (INCLUDED). ALWAYS REPLACE BOTH BATTERIES AT THE SAME TIME. REPLACE BATTERY COMPARTMENT COVER AND SCREW. ALKALINE BATTERIES ARE RECOMMENDED FOR BEST PERFORMANCE.
DO NOT MIX OLD AND NEW BATTERIES.
DO NOT MIX ALKALINE, STANDARD (CARBON-ZINC), OR RECHARGEABLE (NICKEL-CADMIUM) BATTERIES.
NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED.
BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY.
EXHAUSTED BATTERIES ARE TO BE REMOVED FROM THE TOY.
THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED.
RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED.
RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION.
ONLY BATTERIES OF THE SAME OR EQUIVALENT TYPE AS RECOMMENDED ARE TO BE USED.
DO NOT DISPOSE OF BATTERIES IN FIRE, BATTERIES MAY EXPLODE OR LEAK.



87-11504-45628

KAWASAKI® IS A TRADEMARK LICENSED BY
KAWASAKI MOTORS CORP., U.S.A.,
WHICH DOES NOT MANUFACTURE OR DISTRIBUTE THIS PRODUCT.
CONSUMER INQUIRIES SHOULD BE DIRECTED TO
KIDZ TOYZ, INC., 280 NORTH BEDFORD ROAD,
SUITE 203, MT. KISCO, NEW YORK 10549 USA

**MADE IN CHINA
ITEM NO. 77033**