

Kawasaki *i* SOUNDZ Music™

Thank you for purchasing the Kawasaki i soundz audio pro voice mic. This interactive voice mic will bring you hours of fun for the entire family.

Audio Pro Voice Mic

MP3 MUSIC PLAYER JACK
A double jacked wire is included that plugs into your MP3 player and then into the audio pro voice mic speaker.

HEADPHONE JACK
plug your headset into this jack for private listening. Most headphones can be used.

NECKBAND

MODE BUTTON
press the mode button to disconnect the sound from your MP3 player from the main speaker unit. The sound from the MP3 player will still come out of the headset. Your voice will come out of the speaker in the main unit. If you press the mode button again both your voice and the MP3 player will come out of the main speaker unit.

STEREO HEADSET SPEAKERS

WORKS WITH iPod®



HIGH QUALITY SPEAKER

BELT CLIP
There is a belt clip so you can clip it to your belt or pants.

ON/OFF SWITCH
slide this switch to turn the mic on and off.


VOLUME CONTROL
press the plus or minus sign to increase or decrease the volume of your voice.

MIC
adjustable mic to sing into



MP3 PLAYER
after you are done using the MP3 player you must shut it off. If you leave it on it will drain the battery on the musical instrument and deplete the batteries. Please make sure you shut the on/off switch to the off position on the instrument as well.

MP3 PLAYER VOLUME CONTROL
the volume control from your MP3 player controls the volume that comes out of the stereo headset as well as the main speaker unit.



BATTERY REPLACEMENT

REMOVE SCREWS TO OPEN BATTERY COMPARTMENT COVER. THIS UNIT REQUIRES 2 "AAA" BATTERIES (NOT INCLUDED). ALWAYS REPLACE BOTH BATTERIES AT THE SAME TIME. REPLACE BATTERY COMPARTMENT COVER AND SCREWS. ALKALINE BATTERIES ARE RECOMMENDED FOR BEST PERFORMANCE. DO NOT MIX OLD AND NEW BATTERIES. DO NOT MIX ALKALINE, STANDARD (CARBON-ZINC), OR RECHARGEABLE (NICKEL-CADMIUM) BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY. EXHAUSTED BATTERIES ARE TO BE REMOVED FROM THE TOY. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION. ONLY BATTERIES OF THE SAME OR EQUIVALENT TYPE AS RECOMMENDED ARE TO BE USED. DO NOT DISPOSE OF BATTERIES IN FIRE. BATTERIES MAY EXPLODE OR LEAK.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION. NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THE EQUIPMENT SUCH AS MODIFICATIONS THAT VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT.

NOTE: THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS B DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES. THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE IN A RESIDENTIAL INSTALLATION. THIS EQUIPMENT GENERATES, USES AND CAN RADIATE RADIO FREQUENCY ENERGY AND IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTIONS, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS. HOWEVER, THERE IS NO GUARANTEE THAT INTERFERENCE WILL NOT OCCUR IN A PARTICULAR INSTALLATION. IF THIS EQUIPMENT DOES CAUSE HARMFUL INTERFERENCE TO RADIO OR TELEVISION RECEPTION, WHICH CAN BE DETERMINED BY TURNING THE EQUIPMENT OFF AND ON THE USER IS ENCOURAGED TO TRY TO CORRECT THE INTERFERENCE BY ONE OR MORE OF THE FOLLOWING MEASURES:

- REORIENT OR RELOCATE THE RECEIVING ANTENNA.
- INCREASE THE SEPARATION BETWEEN THE EQUIPMENT AND RECEIVER.
- CONNECT THE EQUIPMENT INTO AN OUTLET ON A CIRCUIT DIFFERENT FROM THAT TO WHICH THE RECEIVER IS CONNECTED.
- CONSULT THE DEALER OR AN EXPERIENCE RADIO/TV TECHNICIAN FOR HELP.



87-11504-45628

KAWASAKI® IS A TRADEMARK LICENSED BY KAWASAKI MOTORS CORP., U.S.A. CONSUMER INQUIRIES SHOULD BE DIRECTED TO KIDZ TOYZ, INC., 280 NORTH BEDFORD ROAD, SUITE 203, MT. KISCO, NEW YORK 10549 USA

iPod® is a registered trademark of Apple Computer, Inc. The product sold in this package has not been endorsed or approved by Apple Computer, Inc.

Zune® is a registered trademark of Microsoft Corporation.



BIG MUSIC COMPANY SUBSIDIARY OF **KIDZ TOYZ, INC.**

because kidz like toyz
KIDZ TOYZ, INC. MT. KISCO, N.Y. 10549

For Product Questions,
Call 1-877-KIDZTOYZ (877-543-9869)
Ask for **CUSTOMER SERVICE.**
Only in the U.S. and CANADA

Please visit us on the web at www.kidztoyz.com

MADE IN CHINA
ITEM NO. 77210